


Laptop Desk

Adjustable Foldable Cooling Laptop Stand

User Manual




Please read all instructions carefully before using this product in order to avoid injuries caused by improper operation.

Kapoo Adjustable Foldable Cooling Laptop Stand

Made of premium and light aluminum alloy, this Adjustable Foldable Cooling Laptop Stand with stands years of use. USB cooling fans are designed for fast heat dissipation. With angle measurements on the joints, it is easy to adjust the stand to the most comfortable position, making your computing on bed or couch more enjoyable.


Parts List:

- 1x Laptop Stand
- 1x Mouse Tray
- 1x Washer
- 1x Star Knob
- 2x Edge Stopper
- 1x USB Cable



. 1 .

Terminology:



① Laptop Tray	⑥ Pivot Joint
② Mouse Tray	⑦ Edge Stopper
③ Lower Leg	⑧ Front Lip
④ Middle Leg	⑨ Cooling Fans
⑤ Upper Leg	



Angle Measurements:
Arrow on the button indicates the angle reached

Notice: Locking States



Button In
Not Locked yet



Button out
Locked

Unfolding the Laptop Stand:



Step 1:

Press and hold the button on Joint A to rotate the lower leg until it reaches the desired angle. The button will bounce back out if the lower leg has been locked in place.



Step 2:

Press and hold the button on Joint B to rotate the middle leg until it reaches the desired angle. The button will bounce back out if the middle leg has been locked in place.



Step 3:

Press and hold the button on Joint C to rotate the upper leg until it reaches the desired angle. The button will bounce back out if the upper leg has been locked in place.

Unfolding the Laptop Stand :

Step 1:

Press and hold the button on Joint C to rotate the upper leg so it sits even with the laptop tray.

Step 2:

Press and hold the button on Joint B to rotate the middle leg so it sits even with the upper leg.

Step 3:

Press and hold the button on Joint A to rotate the lower leg so it sits even with the middle leg.




NOTE:
 *DO NOT place a laptop on the unit until you make sure all the legs and the laptop tray are locked into place.
 *Please make sure you have both sides locked at the same angle.
 *If you need to re-adjust the angle of the laptop tray or legs, please refer to the steps in Unfolding the Laptop Stand.
 *Please hold the laptop tray using your fingers if you try adjusting legs on both sides at one time.
 *If you fail to rotate the leg, please make sure you push the button deep in.
 *Adjustments should go from lower leg, to middle leg, to laptop tray when unfolding the unit; when folding the unit, they should be done in the reverse order (laptop tray → middle leg → lower leg)
 *Max. weight capacity is 33 lbs. (15 kg). DO NOT overload!

How to Use Cooling Fans



Used on Your Bed



1. Press and hold the button on Joint A and rotate the lower leg until the arrow points to 150°.
2. Press and hold the button on Joint B and rotate the middle leg until the arrow points to 30°-90°.
3. Press and hold the button on Joint C and rotate the upper leg until the arrow points to 90°-180°.
4. Adjust the middle leg properly to create the most comfortable viewing angle.


Installing the Mouse Tray:




1. Slide the washer onto the star knob.
2. Place the laptop stand with its front lip facing you.
3. Put the mouse tray on the right side of the right upper leg and line up their holes.
4. Screw the knob through the holes.

Installing the Edge Stopper

1. Attach an edge stopper to the front lip of the laptop tray, fitting its groove over the lip. (The flat side of the stopper should sit on the tray.)
2. Rotate the stopper 90 degrees.



Used Outdoors



1. Press and hold the button on Joint A and rotate the lower leg until the arrow points to 120°.
2. Press and hold the button on Joint B and rotate the middle leg until the arrow points to 60°.
3. Press and hold the button on Joint C and rotate the upper leg until the arrow points to 90°.
4. Adjust the upper leg properly to create the most comfortable viewing angle.

Used on Sofa



1. Press and hold the button on Joint A and rotate the lower leg until the arrow points to 0°.
2. Press and hold the button on Joint B and rotate the middle leg until the arrow points to 90°.
3. Press and hold the button on Joint C and rotate the upper leg until the arrow points to 90°.
4. Adjust the upper leg properly to create the most comfortable viewing angle.



1. Press and hold the button on Joint A and rotate the lower leg until the arrow points to 90°.
2. Press and hold the button on Joint B and rotate the middle leg until the arrow points to 180°.
3. Press and hold the button on Joint C and rotate the upper leg until the arrow points to 90°.
4. Adjust the upper leg properly to create the most comfortable viewing angle.

Used on Table



1. Press and hold the button on Joint A and rotate the lower leg until the arrow points to 90°.
2. Press and hold the button on Joint B and rotate the middle leg until the arrow points to 15°.
3. Press and hold the button on Joint A and rotate the lower leg until the arrow points to 30°.
4. Adjust the upper leg properly to create the most comfortable viewing angle.

Many Different Configurations & Heights

