

LED

Use manual
headlight

AUTO LED LIGHTING SYSTEM

Attention

Who has not obtained the professional qualification certificate of the customer installation of this product, such as the scope of the accident and damage compensation claims, which are not in our range of after-sales service.

In addition, the product disassembly, modification is not involved in the warranty claims, so please do not modify user of this product and please use it in correct way

LED headlight*2

Use manual*1

Please don't touch LED chip during installation process. Due to differences in outer design and production process, there might be slight differences among the products, but will not be effect installation and use. Thanks for your understanding!

Installation method

* The descriptions of H4 type installation. Single lamp, no need to unlock button, can be directly inserted into the installation.



Remove the halogen lamps.



Unlock button, put in first.



Accurated the LED lamp alignment buttons for installation.



Plug, to complete the installation.

LED			
According to column 1 template			
PRODUCT QUALITY GUARANTEE CARD			
Order number			
Qty			
Address			
Part name	Type of Particular		
Part No.			
Customer number			
Part number	Part number (optional)		
SERVISEE: 4025 0000			
Send to repair time:			
Damage situation:			
Processing situation:			
Examination record:			
Service man signature:			
Remark:			



LED			
According to column 1 template			
PRODUCT QUALITY GUARANTEE CARD			
Order number			
Qty			
Address			
Part name	Type of Particular		
Part No.			
Customer number			
Part number	Part number (optional)		
SERVISEE: 4025 0000			
Send to repair time:			
Damage situation:			
Processing situation:			
Examination record:			
Service man signature:			
Remark:			