



DOMOTEC®

MODEL:MS-1406



COFFEE GRINDER

SPECIFICATIONS:

Power Source - Voltage AC 220-240V - 50-60Hz 150W

Switch Control - Push Button

Grinding Capacity - 65 grams (approximately)

IMPORTANT SAFEGUARDS

Ensure that the voltage printed on the box corresponds to the supply of electricity in your country.

Due to the very high speed of the motor, NEVER RUN EMPTY OR MORE THAN 60 SECONDS at one time. Always unplug at the time of pouring and cleaning, and avoiding your hand or fingers to be hurt.

This appliance is not intended for use by person (including children) who lack adequate experience, knowledge or capability, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the Appliance

Picture:

Grinder Bowl

Mill blade

Push button

Lid

HOW TO USE YOUR GRINDER

1. Ensure that the power is off when it is not in use.
2. Never use the bowl more than 2/3 full.
3. When in use, top plastic lid must be closed tightly.
4. This machine is intended to grind coffee; grinding other items such as spices will make the coffee taste bad; use separate grinder for separate items. (These items should not be wet)

This machine grinds coffee for any type of coffee maker; for french press, grind coarse (10-12 seconds); for drip, grind medium (15-18 seconds); for espresso machine grind fine (20-25 seconds).

CLEANING

The bowl of the machine can be cleaned with a dry cloth. NEVER IMMERSE your grinder in water, or use too wet a cloth.



THIS SYMBOL ON THE PRODUCT OR IN THE INSTRUCTION MEANS THAT YOUR ELECTRICAL AND ELECTRONIC EQUIPMENT SHOULD BE DISPOSED AT THE END OF LIFE SEPARATELY FROM YOUR HOUSEHOLD WASTE. THERE ARE SEPARATE COLLECTION SYSTEMS FOR RECYCLING IN THERE. FOR MORE INFORMATION PLEASE CONTACT THE LOCAL AUTHORITY OR YOUR RETAILER WHERE U PURCHASED THE PRODUCT.