


Multifunctional Smart electronic count Jump rope Manual

Screen display :

W (Weight : 20-110KG)
L (loop Counter : 0-9999)
T (Timer/Count down timer)
C (Calories : 0-999)



Function Description :

Loop Counter: (0~ 9999 Loop)
Weight setting: (Default 50KG, settable range: 20~150Kg)
Timer/Count down timer: (positive Timer: maximum 59 minutes and 59 seconds, can be set to count down: maximum 60 minutes and 00 seconds, minimum 1 minute and 00 seconds). When the countdown time expires, the alarm will sound for 10 seconds, the positive timer will not alarm.
Target Loop function: (settable range 10~1000 LOOP), when the counter reaches the target loops, the alarm will sound for 10 seconds.
Calorie display function: (Measurement range 0~999 calories)
Back Lights: When Change the battery backlight turns on for 10 seconds, press ON/ SET key in power- on mode, backlight turns on for 10 seconds.
Auto sleep mode Function: in the power-on mode, when there is no key operation and no count input, after 5 minutes enter sleep mode.
When there is a count value, it will be saved, Long press the On key to Clear.

Key function description:

[ON] key: Click to turn on the counter, press and hold for 2 seconds to clear the value, and return to the initial value of power-on except weight.
[SET]: Press and hold for 2 seconds to enter weight setting, then press [SET] key to enter (count down setting), and then press [SET] key to enter (target loop number setting).

[UP] key: When entering the setting mode, the value is increased

[DN] key: When entering the setting mode, the value is down

Instructions:

When starting to use the Jump rope, the counter and time will automatically start counting. If there is a setting count down timer, a BiBi sound will automatically sound as a reminder when time's up. The calorie consumption value will be automatically displayed, and the length of the rope can be adjust based on the user's height

Weight setting: Before starting to use, press and hold the Set button for 2 seconds to enter to set weight, then the weight field value starts to flash, the initial value is 50Kg, use the UP & DN button to adjust to your correct weight (1Kg is a unit, The minimum value is 20Kg, the maximum value is 110Kg), and then press the Set key to complete the setting. (Automatically jump to the time setting, the time value flash).

Time setting: (Alarm reminder): When the time value flash, use the UP& DN key to adjust the time you expect to use (1 minute is a unit, the maximum value is 60 minutes), and press the Set key again to complete the setting (At this time, the value in the time displays the time you set). After the time countdown is complete, a BiBi sound reminder is issued. At this time, the loop Count and timer are stopped.

Counting target number setting: When the count value is 0, use UP & DN to adjust to the number of Loops you expect to use, (minimum from 10 to maximum 1000) Press the Set key again to complete the setting, after the Loop count reaches your setting number, A BiBi sound is issued to remind you that the loop and time will stop.

When you need to use it again, press and hold the ON button for 2 seconds, other settings and values clear, except the weight setting.

Must see!


Smart jump rope guide!

STEP 1

Find this groove like Voldemort's nose! It is divided into the front door and the back door! If you enter the wrong door! It will cause "fall off the rope" and "count inaccurate" problems!

STEP 2

Correctly distinguish front and back doors!



Warning :

When the display is blurred, use a screwdriver to open the battery cover to change a new battery, battery model CR2032*1PCS.

Avoid vigorously throwing the Jump rope on the ground.

Avoid heavy pressure on the LCD display and keys.

Avoid placing in a humid environment and entering water.

RoHS CE FC

MADE IN CHINA

STEP 3

Go through the front door, go back through the back door

STEP 4

Tighten the rope, the smart jump rope can work normally at this time! Normal counting!

