

THE MANUAL OF TEMPERATURE ADJUSTABLE ELECTRIC BLANKET

IMPORTANT NOTES Read manual carefully before operating,Note to keep the manual for the reference in the future.

一、 use

Electric blanket are sold well due to its high quality and reliable safety since it put into the market.As the product used in bed for warmth and health care in the winter,especially in the cold area and southern humid and rainy area,the product has the obvious auxiliary effect on curing the arthrititis and sciatica,it is the idea product preventing coldness.

二、 Features

- 1.The product passed the detection of National Domestic Appliance Detection Center,the result showed that all the technical parameters of the product meet the demands of the National Standard such as GB4706.8-2008;GB4706.1-2005 and QB/T2994-2008.
- 2.The heating components made with the new process like spiral-wound and external extrusion,so it has the features such as good insulation ability and high tensile strength as well as long life,etc.
- 3.Using the two-channel switch including double connection and double break,it was divided into two stages including high and low tmperature,also it can be adjusted random.It has the following features:big heating surface,low electricity consumption,uniform tmperature and beautiful outside view.
- 4.The dual temperature and dual control electric blanket adopt the individual control on the left and the right,the temperature can be adjusted by your desire.

三、 Technical parameters

Rated voltage:220V,Frequency:50Hz.
Withstand voltage:4000v.
Electric shock protection:II class electrical appliance

Type	Specification	Rated Power	Remark
TT160X130-1X	Micro-computer Controlled And Automatic Electric Blanket	100W	
TT160X120-1X	Dual Temperature And Dual Control	100W	
TT150X120-1X	Double	100W	
TT150X120-1X	Double	100W	
TT160X80-1X	Single	60W	

四、 Operating Instruction

- 1.laying the electric heating bianket
 - The electric heating blanket should be laid on the relatively hard and unadjustable mattress,the blanket body should be laid flat from the shoulder to the foot while sleeping.
 - Both the front and the back side of the electric heating blanket can be operated flat,the side to connect thecontroller should be planced on the position of the shoulder,which will make it convenient to operate.
 - The four ring buttons of the blanket body should be fixed tightly on the mattress or the bed after you laying the electric heating blanket,which will make it uneasy to move and produce crease. (The crease part of the electric heating blanket iseasy to produce high temperature and cause danger).
 - To keep the electric heating blanket clean,flat and to protect the surface of the blanket from producing the small ball,please cover the bedspread on the blanket.(Dong't cover the carpet or the cotton mat on the blanket,it will affect the blanket to emit heat).
- 2.Operating the electric heating blanket
 - Please preheat before you sleep from 30 minutes to 1 hour.Plug the controller into ghe power socket and make it connect fimly,Snap switch to high level.the blanket will be warmed up.
 - You may snap switch to low level while sleeping,please snap switch to off if you don't want to heat the blanket.
 - The controller of the blanket should be exposed to air,don't cover or press the controller by the quilt or the pillow.
- 3.Finishing
 - Please shut off the blanket after you get up,and unplug the blanket from the powwer socket.

五、 Cautions

- It may cause human injury or property damage if you misuse or don't operate by the provision of the blanket,this is the same as all other electric heating products.The following should be read carefully before you operating the blanket.
- 1.Don't allow the following person to operate the blanket,the person who can not look after himself,the infants,the person who is insensitive to heat,who takes the somnolent medicine,the person who is drunk and who is very tired.
 - 2.The blanket is unsuitable to operate independently by children,unless his parents or gusrdian have finished setup of the blanket in advance,or have given them full instuctions on how to operate the blanket.
 - 3.The blanket is not intended for hospital use.
 - 4.Dont't fold,ruffle,roll while operating,this will cause danger of fire resulted from the damage of the heating material of overheat.
 - 5.Don't operate on the foldable bed including wire bed and similar sofa.often check the blanket and the cord to prevent them from cockling.
 - 6.Don't use the blanket as the warmer utensil for some pets such sa dog and cat ,because they will bite the blanket body and power cord,it will cause fire.
 - 7.Prohibit to use with other heating advice, the blanket body will cause damage because of accumulated high temperature.
 - 8.Only use the electric heating blanket sa the lower blanket,the blanket should be operated flat at each use.
 - 9.Don't fix the electric blanket with the nails or use similar methods,thes will cause damage of the blanket or happen risks of electric shocks.
 - 10.Don't use the electric heating blanket while it is wet.
 - 11.Don't operate the electric heating blanket out of the power of 220 volts.
 - 12.Unplug the controller from the power socket while stopping using.Caution,Don't pull the power cord or connecting soft wire to unplug.Prohibited to switch on while it is unattended.
 - 13.Don't wash or dry wash.
 - 14.Don't try to disaaemble,repair or alter the electric heating blanket,including change the fuse by yourself.It should be repaired by the factory while it is out of order.Otherwise it may cause fire to hurt person.

六、 Maintain and storage

- 1.Maintain of the power cord of the controller
 - Please wipe the surface with the neutral detergent while it is dirty and dry it with soft cloth.
 - Don't clean with industrial solvents like benzene and kerosene.
- 2.Storage cautions
 - Store electric heating blanket till it is dry.It can be hanged at the ventilated site to let is naturally dry or switched on in attendance for 1or 2 hours to remove humidity.Don't put it in the sun or iron,which will cause aging of insulated layer of the electric heating blanket and affect safety.
 - The dry electric heating blanket should be folded without any cackle,stored on the cotton quilt,the blanket without pressing will avoid crease.
 - Don't use any mothproofing agent like naphthalene,because this agent will damage the inslated material

Limited Warranty Card

		Recorded By The Service Employee	
Invoice No.		Customer Name	
Purchase Date			
Customer Address			
Repair Record	Repair Items	Date	Handler

